


INSTALLATION GUIDE

VIGILEC®
zero *plus* sensor

Vigilec Zero plus sensor

1





2





3



4





II




III

5



6



7

